



SurfPrep Foam Conversion Chart

RED ALUMINUM OXIDE

Description	Grit	Finish/Scratch	Purpose
Coarse	36	60-80	REMOVES
Coarse +	46	80-100	REMOVES
Medium	60	120-150	REMOVES
Medium +	80	150-180	PREPARES
Fine	100	220-240	PREPARES
Very Fine	150	280-380	FINISHES
Super Fine	180	450-600	FINISHES
Super Fine +	220	600-700	FINISHES

5mm sanding sponges – Awesome for FLAT scuff sanding. Although the abrasive may feel aggressive on the surface of the pad the magic is the gentle sanding it will provide without deep scratches left behind. This sanding sponge is great for sanding raw wood surfaces as well as finished surfaces. NOT for contour surfaces that you don't wish to flatten or break edges.

10mm sanding sponges – Magically can scuff sanding both flat and soft profiles. When depth and ease of slight angles and profiles are needed, these pads will scuff sand without leaving deep scratches. Examples of use would be inside shaker door panels, beveled profiles on doors, sloped surfaces and curves.

½" sanding sponges – Amazing ability to shape itself to curved and round profiles while scuff sanding. A must for all the rounds, curved profiles that are hard to sand without flattening an edge. Because of its soft backing, the abrasive will NOT aggressively sand away deep scratches, rough profiles, etc. It is designed to ride the contour and SCUFF sand NOT stock removal of chatter marks or old paint etc.